



Notes:

1. This detail is appropriate for hot-asphalt, torch-welded, and cold process applications. For self-adhered systems, adapt modifications addressed in Section 5 of Construction Details.
2. Nail base sheet 12" o.c. through tin-discs in all directions.
3. Fasten Flintlastic cap sheet 9" o.c. along top edge.
4. Apply one ply Flintlastic cap sheet extending from top outside edge of parapet wall. Nail 9" o.c. through tin-discs along top of parapet wall.

**CertainTeed**  
SAINT-GOBAIN  
**Commercial Roofing**

ISSUE DATE	REVISION	DRAWING NUMBER
8/21/2013	B	<b>CT-06</b>
SCALE		
Not to Scale		Sheet 1 of 1

**Base Flashing & Wall Covering On  
Wood Parapet Wall**